



Meaningful Innovation.

WEEE Number: 80133970

## INSTRUCTION MANUAL TABLE LAMP

### TECHNICAL DATA

MODEL	VT-7544
SKU	7007, 7008, 7009
LUMENS	300LM
BEAM ANGLE	180°
UNIT COLOR	WHITE/BLACK/CORTEN
CABLE LENGTH	2 M
INPUT VOLTAGE	DC: 5V, 2A
ADAPTER OUTPUT [NOT INCLUDED]	DC: 5V, 1A~2A
MATERIAL	ALUMINIUM
DIMENSION	D140*H1300mm<Max>
BATTERY CAPACITY	4400mAH
CHARGING TIME	6-8 Hours
WORKING TIME	6 Hours <Max>
TOCUH DIMMING LEVEL	10~100%



### INTRODUCTION

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. This product is warranted for manufacturing defects only.

### WARNING!

1. Please make sure to turn off the power before starting the installation
2. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.




**MULTI-LANGUAGE  
MANUAL QR CODE**


Please scan the QR code to access the manual in multiple languages.



This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.




Non-replaceable light source



### OPERATION CAUTIONS:

1. Please do not put the lamp on the high-temperature surfaces, and do not use it in flammable or humid environment, to avoid the breakdown, short circuit etc.
2. The adapter must be under the specialized range.
3. Please ensure to place the lamp on a steady base only.

### PACKAGE CONTENT



### OPERATION GUIDE


1. Tap on the button at the top of lamp to switch on/off the lamp
4. **For Dimming function** - Make sure the light is ON, tap on the touch button and hold for the light to increase/decrease the brightness. When turning on the lamp next time, the light brightness level will be the same as the last setting.

### COLOR LED INDICATOR

1. **RED COLOR INDICATOR** - Charging is in progress.
2. **GREEN COLOR INDICATOR** - The battery is full charge

### MAINTENANCE

1. Please clean the lamp once in every two months to keep it smooth and bright.
2. Use cleaning cloth and water to clean the dust
3. For filthy marks, please use cleaning cloth and soapsuds.
4. Please do not clean the lamp by high-volatility and high-corrosive liquid which can lead to discoloring or damaging the lamp.



IN CASE OF ANY QUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: [SUPPORT@V-TAC.EU](mailto:SUPPORT@V-TAC.EU)  
 MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS.  
 V-TAC EUROPE LTD. BULGARIA, PLOVDIV 4000, BUL.L.KARAVELOW 9B